

Monsoon Horizontal shower

SUSSEX

Product code

MSHAHSS Horizontal shower

Installation guidelines

- Flush water lines prior to fitting the shower.
- Apply thread tape or sealant 1/2" BSP thread protruding from the wall.
- Position Dress Ring and attach Horizontal Arm.
- Attach Shower Head to Arm.
- Operate tapware and check all connections for water leaks.

