

# Suba Robe hook

# SUSSEX

## Product code

BRH          Robe hook

## Installation guidelines

- The Robe Hook is supplied pre-assembled within its packaging.
- Using the supplied 2mm Allen Key, loosen the Stainless Steel Set Screws and remove the Brass Wall Fixing.
- Drill a 6.5mm hole, fit Tox Plug and secure the Brass Wall Fixing using the Fastening Screw.
- Fit the Robe Hook over the Brass Wall Fixing, aligned square, and tighten the Stainless Steel Set Screw.

